

SS8 Timer Quick Instruction Guide:

- 1) Press and release the [MODE] button until the word 'YEAR' comes up on the display.
- 2) Press the [M+/ZONE+/YEAR+] button until the correct year is displayed.
- 3) Press the [NEXT/ON/OFF] button one time.
- 4) Press the [M+/ZONE+/YEAR+] button until the correct month is displayed.
- 5) Press [DAY/DST] button until the correct day is displayed.
- 6) Press the [NEXT/ON/OFF] button two times.
- 7) Press the [M+/ZONE+/YEAR+] button until the correct zone is displayed for your location.
(Note: The zone is NOT your time zone. It is how far North or South you are in North America.)
- 8) Press the [NEXT/ON/OFF] button one time.
- 9) This is your approximate SUNUP time. To adjust this time, press the [HOUR+/YEAR-] button to change the hour and the [M+/ZONE+/YEAR+] to change the minutes.
- 10) Press the [NEXT/ON/OFF] button one time.
- 11) This is your approximate SUNSET time. To adjust this time, press the [HOUR+/YEAR-] button to change the hour and the [M+/ZONE+/YEAR+] to change the minutes.
- 12) Press the [NEXT/ON/OFF] button one time. 'Year' should be displayed again.
- 13) Press the [MODE] button one time.
- 14) Press the [HOUR+/YEAR-] button to change the hour and the [M+/ZONE+/YEAR+] to change the minutes to set your current time.
- 15) Press the [MODE] button one time.
- 16) To set your ON time for a FIXED time, press the [DAY/DST] button until you see dashes (--:-- --) in the display. To set your ON time for SNST, press the [DAY/DST] button 11 more times, then skip to step 19.
- 17) Press the [DAY/DST] button one more time.
- 18) To adjust this setting, press the [HOUR+/YEAR-] button to change the hour and the [M+/ZONE+/YEAR+] to change the minutes.
- 19) Press the [NEXT/ON/OFF] button one time.
- 20) To set your OFF time for a FIXED time, press the [DAY/DST] button until you see dashes (--:-- --) in the display. To set your OFF time for SNUP, press the [DAY/DST] button 11 more times, then skip to step 23.
- 21) Press the [DAY/DST] button one more time.
- 22) To adjust this setting, press the [HOUR+/YEAR-] button to change the hour and the [M+/ZONE+/YEAR+] to change the minutes.
- 23) Press the [NEXT/ON/OFF] button one time.
- 24) If you have no other ON or OFF times, Press the [MODE] button one time. This will put you in AUTO mode with the current time displayed.

Connect with Us



Intermatic.com

